



SZALACTÁL / TRAY
400-0-00 405 MM ↔



SÜTEMÉNYESTÁL / PLATTER
431-0-00 280 MM ↔



SZENDVICSTÁL / SANDWICH DISH
435-0-00 500 MM ↔
436-0-00 370 MM ↔
437-0-00 235 MM ↔



SÜTEMÉNYESTÁL / CAKE PLATE
315-0-00 320 MM ↔




KENYÉRFOSÁR / BREAD BASKET
380-0-00 305 MM ↔



TÁLCA / PLATTER
422-0-00 270 MM ↔
424-0-00 460 MM ↔



GYÜMÖLCSSTÁL / FRUIT COMPOT
311-0-00 240 MM ↔
315-0-00 205 MM ↔



LEVÉLALÁLÓ TÁL / LEAF DISH
200-0-00 240 MM ↔
202-0-00 240 MM ↔
204-0-00 200 MM ↔



CITROMFOGÓ / LEMON HANDLE
XXXXX-0-05



LEPKEFOGÓ / BUTTERFLY HANDLE
XXXXX-0-17



MADÁRFOGÓ / BIRD HANDLE
XXXXX-0-05



CSAVARTFOGÓ / TWISTED HANDLE
XXXXX-0-06

OSIER

AZ OSIER – FONOTT – FORMA A HERENDI PORCELÁNMANUFAKTÚRA EGYIK LEGISMERTEBB ÉS LEGKEDVELTEBB TERMÉKCSALÁDJÁ. A KOSÁRFONÁSRA EMLÉKEZTETŐ SZEGÉLY RELIEF A BAROKK KOR KEDVELT DÍSZÍTÓ ELEMÉNEK VOLT.

AZ EURÓPAI PORCELÁNMANUFAKTÚRÁK, SZINTE KIVÉTEL NÉLKÜL SZÍVESEN ALKALMAZTÁK TERMÉKEIKEN. EZT AZ IRÁNYZATOT KÖVETVE, AZ ILY MÓDON DÍSZÍTETT TERMÉKEK A MANUFAKTÚRÁBAN MÁR A KEZDETEKTŐL FOVA MEGJELENTEK ÉS A LEGSZÉLESEBB VÁLASZTÉKOT NYÚJTÓ TERMÉKCSALÁDDÁ VÁLVA NAPJAINKBAN IS DOMINÁNS SZEREPET TÖLTENEK BE. A KLASSZIKUS FORMÁT KEDVELŐK ITT LEIK MINDAZON SZÉPSÉGET, AMELY ÉVSZÁZADOK ÓTA AZ EURÓPAI PORCELÁNGYÁRTÁST JELLEMZI.

OSIER

THE OSIER – WICKER – FORM IS ONE OF THE PORCELAIN MANUFACTORY'S BEST-KNOWN AND MOST POPULAR COLLECTIONS. THE BORDER RELIEF REMINDING BASKET WEAVING WAS A POPULAR DECORATIVE ELEMENT OF THE BAROQUE: IT WAS OFTEN USED BY ALMOST ALL EUROPEAN PORCELAIN MANUFACTORIES ON THEIR PRODUCTS. FOLLOWING THIS STYLE, PRODUCTS DECORATED THIS WAY HAVE ALREADY BEEN MADE IN THE MANUFACTORY SINCE THE BEGINNING, AND BECOMING THE COLLECTION WITH THE WIDEST SELECTION THEY STILL PLAY A DOMINANT ROLE. THOSE WHO LIKE CLASSIC FORMS FIND IN THEM ALL THE BEAUTY THAT HAS CHARACTERIZED THE EUROPEAN PORCELAIN MANUFACTURING FOR CENTURIES.



HEREND PORCELAIN MANUFACTORY LTD.
H-8440 HEREND KOSSUTH UTCA 140.
TEL.: +36 88/523-185
FAX: +36 88/261-518
WWW.HEREND.COM
INFO@HEREND.COM

EGYÉB FOGÓKÓD VARIÁCIÓK / OTHER HANDLE VARIATIONS

OSIER



HEREND PORCELAIN



MÁRTÁSTÁL / SAUCE BOAT
218-0-00 0,22 L



SZALVÉTAGYŰRŰ / NAPKIN RING
270-0-00 60 MM ↔
272-0-00 45 MM ↔



CSONTTÁNYÉR / CRESCENT
530-0-00 188 MM ↔
531-0-00 205 MM ↔



TÁLCA / BOWL
364-0-00 0,42 L



BEFÖTTETÁLCA / FRUIT BOWL
329-0-00 145 MM ↔
330-0-00 170 MM ↔



TÁL / BOWL
354-0-00 1,21 L
355-0-00 0,62 L
356-0-00 0,43 L



VAJTARTÓ, RÓZSAFOGÓVAL / BUTTER DISH, ROSE KNOB
390-0-00 190 MM ↔
393-0-09 155 MM ↔



TOJÁSTARTÓ / EGG CUP
264-0-00 110 MM ↔



LEVESTÁL, RÓZSAFOGÓVAL / SOUP TUREEN, ROSE KNOB
22-0-09 4,2L
23-0-09 3,0L
25-0-09 1,05 L



FŐZELÉKSTÁL / VEGETABLE DISH
146-0-00 2,15L
148-0-00 1,4L
149-0-00 1,1L



PECSENYESTÁL / OVAL DISH
101-0-00 415 MM ↔
102-0-00 365 MM ↔
103-0-00 345 MM ↔
118-0-00 310 MM ↔



TÁLKA, OVÁL / OVAL DISH
211-0-00 265 MM ↔
212-0-00 220 MM ↔
213-0-00 200 MM ↔



SÓ- ÉS BORSTARTÓ / TWIN SALT CELLAR
253-0-00 150 MM ↔



MÁRTÁSTÁL / SAUCE BOAT
220-0-00 0,5 L



SALÁTÁSTÁL / SALAD DISH
181-0-00 1,2 L
192-0-00 0,38 L



SALÁTÁSTÁL / SALAD DISH
181-0-00 1,7 L
182-0-00 1,45 L



TÁL, KERÉK / ROUND DISH
156-0-00 335 MM ↔
157-0-00 320 MM ↔
158-0-00 305 MM ↔



LAPOSTÁNYÉR / DINNER PLATE
521-0-00 230 MM ↔
524-0-00 255 MM ↔
527-0-00 285 MM ↔



CSEMEGETÁNYÉR / DESSERT PLATE
512-0-00 125 MM ↔
515-0-00 170 MM ↔
517-0-00 195 MM ↔
519-0-00 210 MM ↔



MÉLYTÁNYÉR / SOUP PLATE
503-0-00 250 MM ↔
504-0-00 235 MM ↔
505-0-00 210 MM ↔



TEÁSKANNA, RÓZSAFOGÓVAL
TEAPOT, ROSE KNOB
603-0-09 1,8 L
604-0-09 1,25 L
605-0-09 1,0 L
606-0-09 0,8 L



KÁVÉSKANNA, RÓZSAFOGÓVAL
COFFEEPOT, ROSE KNOB
611-0-09 1,5 L
612-0-09 1,25 L
613-0-09 0,9 L
614-0-09 0,7 L
615-0-09 0,45 L



TEJZÍNESKANNA / CREAMER
642-0-00 0,28 L
643-0-00 0,22 L
644-0-00 0,16 L
645-0-00 0,07 L



TEJZÍNESKANNA / CREAMER
647-0-00 0,30 L
648-0-00 0,22 L
649-0-00 0,12 L



CUKORTARTÓ, RÓZSAFOGÓVAL
SUGAR BASIN, ROSE KNOB
471-0-09 135 MM ↔
472-0-09 125 MM ↔



CUKORTARTÓ, RÓZSAFOGÓVAL / SUGAR BASIN, ROSE KNOB
481-0-09 125 MM ↔
482-0-09 115 MM ↔
483-0-09 95 MM ↔
484-0-09 90 MM ↔



TEÁSCSÉSZÉ ÉS ALJ / TEACUP & SAUCER
724-0-00 0,2 L



TEÁSCSÉSZÉ ÉS ALJ / TEACUP & SAUCER
733-0-00 0,31 L



KÁVÉCSÉSZÉ ÉS ALJ / COFFEECUP & SAUCER
706-0-00 0,21 L



MOKKÁCSÉSZÉ ÉS ALJ / MOCCACUP & SAUCER
709-0-00 0,11 L



MOKKÁCSÉSZÉ ÉS ALJ / MOCCACUP & SAUCER
711-0-00 0,11 L



MOKKÁCSÉSZÉ ÉS ALJ / MOCCACUP & SAUCER
735-0-00 0,08 L



TEÁSCSÉSZÉ ÉS ALJ / TEACUP & SAUCER
730-0-00 0,22 L



TEÁSCSÉSZÉ ÉS ALJ / TEACUP & SAUCER
701-0-00 0,3 L



LEVESCSÉSZÉ ÉS ALJ / SOUPCUP & SAUCER
718-0-00 0,3 L



LEVESCSÉSZÉ ÉS ALJ / SOUPCUP & SAUCER
743-0-00 0,36 L



LEVESCSÉSZÉ ÉS ALJ / SOUPCUP & SAUCER
750-0-00 0,31 L



LEVESCSÉSZÉ ÉS ALJ, RÓZSAFOGÓVAL
SOUPCUP & SAUCER, ROSE KNOB
744-0-09 0,3 L



CUKORCSÉSZÉ / SUGAR BOWL
492-0-00 105 MM ↔
491-0-00 140 MM ↔



SÓ, ÉS BORSZÓRÓ / SALT AND PEPPER SHAKER
249-0-00 55 MM ↕
250-0-00 55 MM ↕